





KS3B-1100

# Congratulations on your new coffee scale

For more information and the instruction manual in multiple languages, simply scan the QR code

If you wish, you can register your product in the app for easy access later

Happy brewing!





www.wilfa.com

# SCAN THE QR CODE TO ACCESS THE INSTRUCTION MANUAL IN YOUR LANGUAGE.

- Scan QR koden for å lese bruksanvisningen på ditt språk.
- Skanna QR-koden för att läsa bruksanvisningen på ditt språk.
- Scan QR-koden for at læse brugsanvisningen på dit sprog.
- Skannaa QR-koodi lukeaksesi käyttöoppaan omalla kielelläsi.
- Scannen Sie den QR-Code, um die Bedienungsanleitung in Ihrer Sprache zu lesen.
- Scan de QR-code om de gebruiksaanwijzing in uw taal te lezen
- Zeskanuj kod QR, aby przeczytać instrukcję obsługi w swoim języku.
- Scannez le code QR pour lire le manuel d'instructions dans votre langue.
- Scansiona il codice QR per leggere il manuale di istruzioni nella tua lingua.
- Escanea el código QR para leer el manual de instrucciones en tu idioma.

# PRODUCT OVERVIEW





## **MANUAL MODE**

In manual mode, you have complete control over the weighing and timing process.

Press the Power button to start the timer, and the Tare button to tare the scale.




## **ESPRESSO MODE** •

In Espresso mode, both taring and timing are automated.

After placing the cup and once the weight stabilises, the scale automatically tares to zero and starts the timer when it detects water flow.

The timer stops when the water flow ceases.




# GRINDER MODE ■


In grinder mode, the scale operates without a timer.

After placing the cup and once the weight stabilises, the scale automatically tares to zero.

Start the coffee grinder. When the flow of ground coffee stops, the final weight is displayed.



#### **CHARGING**



- Before charging, make sure the on/off switch is set to on.
- Do not use the scale while charging.
- During charging, the battery icon will blink to indicate that the scale is charging.
- When fully charged, the icon will stop blinking.
- When the battery level is low the display will show "Lo".



# **SOUND**

You can only change the sound setting when the scale is powered on and the display shows the full screen, as illustrated.



- To turn the sound **off**: Press and hold the Tare button until you hear two short beeps.
- To turn the sound **on**: Press and hold the Tare button until you hear one long beep.

#### **GUARANTEE**



Wilfa issues a 5 year guarantee on this product from the day of purchase. The guarantee covers production failure or defects that arise during the guarantee period. Your purchase receipt works as proof towards retailer if claiming your guarantee. The guarantee is valid only for products that are bought and used in private households. The guarantee is not valid if the product is used commercially. The guarantee is not valid if the product is misused, used by negligence, if not following instructions given by Wilfa, if modified or if unauthorized reparation is done. The guarantee is also not valid for normal wear of the product, misuse, lack of maintenance, use of wrong electrical voltage or:

- Overloading of product
- Parts you can expect being replaced regularly (e.g. battery etc.)

Instruction manual is also available at our website; wilfa.com

## **PRODUCT SPECIFICATIONS & MAINTENANCE**

Weighing range	0.1-1100g
Unit and division	g: division value is 0.1g
	oz: division value is 0.01 oz
Timer	00:00-9:59 seconds
Battery type	Rechargeable lithium battery 480mAh
Charging plug	USB-C

- Clean the weighing surface after use. Use a damp cloth to wipe the weighing surface.
- Do not place objects on the scale for an extended period of time.
- Store the product in a dry, stable and non corrosive environment.

#### SUPPORT AND SPARE PARTS

For support please visit us at **wilfa.com**, and see our customer service/ support page. Here you will find frequently asked questions, spare parts, tips and tricks and all our contact information.

#### RECYCLABILITY

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm



to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling free of charge.

